

Q. 600
WIRING
DIAGRAM


Q. 100
SCHEMA DE
CABLAGE

Q. 200
SCHALTPAN

Q. 100
DIAGRAMA
ELECTRICO

Q. 500
SCHEMA
IMPIANTO
ELETTRICO

For XT600E
Pour XT600E
Für XT600E
Para XT600E
Per XT600E



1. Ignitor unit
2. Main switch
3. Clutch switch
4. Front brake switch
5. Ignition coil
6. Spark plug
7. Rear brake switch
8. Sidestand switch
9. A.C. magneto
10. Rectifier/regulator
11. Tail/brake light
12. Rear flasher light (Right)
13. Rear flasher light (Left)
14. Fuse
15. Battery
16. Starter relay
17. Starter motor
18. Diode
19. Neutral switch
20. Relay
21. "START" switch
22. "ENGINE STOP" switch
23. "HORN" switch
24. "TURN" switch
25. "LIGHTS" (Dimmer) switch
26. "LIGHTS" switch
27. Horn
28. Flasher relay
29. Front flasher light (Left)
30. Front flasher light (Right)
31. Meter light
32. "HIGH BEAM" indicator light
33. "TURN" indicator light
34. "NEUTRAL" indicator light
35. "REV." indicator light
36. Auxiliary light
37. Headlight